

# Microclene Australia

Cleaning the air you breathe..!



## MC 750 Instruction Manual

This unit is supplied with a 2 meter lead with an IEC plug to fit the socket on the machine. A 2 meter extension lead is available as an optional accessory. Use the 4 brackets on the rear of the machine to mount it on a wall or ceiling.

### **Before using the filter**

**It is best to do a quick test to enable you to know when the filter media needs replacing.**

- 1 Turn the machine on.
- 2 Place this sheet of paper over the grill.
- 3 Switch off machine taking note of the seconds hand on you watch.
- 4 Time how long it takes for the paper to fall away from the grill and record this time on the machine.
- 5 Repeat test weekly or monthly depending on use.
- 6 When the time taken to fall away is half of the original time, replace filter

To replace filter pad, loosen the three Machine screws holding the grill on, do not completely undo them, lift off grill, replace filter then replace grill and tighten screws, making sure that the washers are on the outside of the grill, not under it.

### **Microclene Australia Pty Ltd**

Office 227A Belmore Rd, Riverwood, NSW 2210 Australia  
Phone: 02 9679 8988 | Fax: 02 9679 8988 | [www.microclene.com.au](http://www.microclene.com.au)