

INSTRUCTIONS FOR THE MC3000



This machine comes with a 6 metre power lead which needs to either have a male electrical fitting attached and then plugged into a standard 240 V power outlet, or, alternatively, the unit can be hard wired into the lighting circuit to come on when the lights do.

The unit needs to be suspended from the ceiling (or practical beams) using 4 chains (or steel cable) attached to the 4 suspension points on top of unit.
The bottom of the unit should be 2.5 to 3.5 metres above the floor for optimum air circulation.

Before using the unit, it is advised to do a quick test to help you determine when the filter pad needs replacing.

Turn the filter on when in fixed position.

Place this instruction sheet over the air intake area; leave for approximately 10 seconds and then switch the unit off. Simply note the time (in seconds) it takes for the paper to fall away from the grille (generally 30 to 40 seconds). Repeat this test periodically until the time reduces to half the original time-This indicates the filter requires changing.

To change the filter pads, simply unscrew the butterfly nuts holding the cover in position and remove the cover.

Place new filter into the filter cavity, replace the cover and refit the butterfly nuts to hold cover in place. Repeat process for other 3 pads.
Remove the old filters and dispose to waste.

REMEMBER TO WEAR YOUR FACEMASK WHILST PERFORMING THIS TASK

Microclene Australia
Cleaning the air you breathe.